


SMS 11.2 Tutorial

Observation



Objectives

This tutorial will give an overview of using the observation coverage in SMS. Observation points will be created to measure the numerical analysis with measured field data and calibration. Observation arcs will be set to view the results of cross sections or river profiles.

Prerequisites

- None

Requirements

- FESWMS or Generic Mesh
- Map Module
- Mesh Module

Time

- 30-45 minutes

AQUAVEO™

1	Introduction	2
2	Opening the Data	2
3	Viewing Solution Data	3
4	Creating an Observation Coverage	4
5	The Observation Coverage	4
5.1	Creating a Measurement	5
6	Creating an Observation Point	5
6.1	Using the Calibration Target	7
6.2	Multiple Measurements	8
7	Reading a Set of Observation Points	8
8	Generating Error Plots	10
8.1	Plot Data	11
8.2	Using the Computed vs. Observed Data Plot	11
8.3	Using the Error Summary Plot	12
9	Calibrating the Model.....	12
9.1	Editing the Material Properties	12
9.2	Computing a New Solution	12
9.3	Reading the New Solution	13
9.4	Fine-tuning the Model	13
10	Using the Error vs. Simulation Plot.....	14
11	Generating Observation Profile Plots.....	15
12	Generating Time Series Plots.....	17
13	Conclusion.....	19

1 Introduction

An important part of any computer model is the verification of results. Surface water modeling is no exception. Before using a surface water model to predict results, the model must successfully simulate observed behavior. Calibration is the process of altering model input parameters (within an accepted range) until the computed solution matches observed field values (or at least as well as possible). SMS contains a suite of tools in the *Observation Coverage* to assist in the model verification and calibration processes.

The observation coverage consists of *Observation Points* and *Observation Arcs*, which help analyze the solution for a model. Observation points can be used to verify the numerical analysis with measured field data and calibration. They can also be used to see how data changes through time. Observation arcs can be used to view the results for cross sections or river profiles. This tutorial is based on a *FESWMS* finite element model, but the calibration tools in SMS can be used with any model.

Note: If the user does not have the *FESWMS* interface enabled, generic solutions will be provided to complete this tutorial. Follow the instructions labeled *Generic Module Instructions* where applicable.

2 Opening the Data

To open the *FESWMS* simulation and solution data:

1. Select *File / Open...* The *Open* dialog will appear.
2. Open the file “observe1.sms” from the Data Files Folder for this tutorial.
 - If there is still a geometric figure open from a previous tutorial, the user will be asked if they want to delete existing data. If this happens, click the **Yes** button.

Generic Module Instructions:

1. Select *File / Open...* to bring up the *Open* dialog.
2. Open the files “observe1.2dm” and “observe1.h5.” These are the mesh and FESWMS data files, respectively.

3 Viewing Solution Data

An initial solution has already been created with this data file and was opened with the project. When the solution file is opened into SMS, various scalar and vector datasets are created. By default, the active datasets are the “velocity mag” scalar dataset and the “velocity” vector dataset. Several display options should be changed. To do this:

1. Right-click on the “Mesh Data” folder in the Project Explorer and select **Display Options...** This will open the *Display Options* dialog.
2. Click the **All off** button and then turn on the *Contours*, *Nodestrings* and *Mesh boundary* options.
3. Click **OK** to exit the *Display Options* dialog.

After setting the display options, the mesh data will appear as shown in Figure 1.




Figure 1 Mesh contained in observe1.sms

4 Creating an Observation Coverage

The calibration tools utilize observation features in an observation coverage. To create an observation coverage:

1. Click on the “default coverage” in the Project Explorer to make it the active object. It will most likely be at the bottom of the Project Explorer, under the “Map Data” heading.
2. Right-click on the “default coverage” and select **Rename**. Change the name to “calibration data.”
3. Right-click on the coverage again and select *Type*. Change the type to *Generic* → **Observation**.

The *Observation Coverage* dialog can now be used to specify what data to use in calibrating the model and to edit observation points and arcs. To bring up the *Observation Coverage* dialog:

1. Select *Feature Objects* / **Attributes...**

5 The Observation Coverage

In this tutorial, observation points will be used to calibrate the model; however, observation arcs or a combination of arcs and points can be used instead depending on the data collected in the field. Observation arcs work similar to observation points. Differences will be pointed out as the tutorial proceeds.

The *Observation Coverage* dialog can show the attributes for either observation points or observation arcs, but not both at the same time. The *Feature object type* combo box (in the upper right corner) determines which attributes are currently being shown in the *Observation Coverage* dialog.

The upper spreadsheet is called the *Measurements* spreadsheet and the lower spreadsheet is called the *Observation Objects* spreadsheet. The titles of these spreadsheets change depending on what is selected as the feature object. Right now, the title of the *Measurements* spreadsheet is simply “Measurements” and the title of the *Observation Objects* spreadsheet is “Observation Points.” Select *arcs* as the feature object and the titles of the *Measurements* and *Observation Objects* spreadsheets will change to “Flux Measurements” and “Observation Arcs,” respectively.

Before continuing, it should be pointed out that observation points use single values measured in the field such as velocity and water surface elevation to calibrate the model. On the other hand, observation arcs use fluxes that have been computed across the arc to calibrate the model. Therefore, measurements for observation arcs are called “Flux Measurements.”

5.1 Creating a Measurement

By default, when the *Observation Coverage* dialog is first opened, a *Measurement* does not exist. A measurement represents the solution data that is compared to the observed field data in the calibration process. For observation points, a measurement is tied to either a scalar or a vector dataset. This dataset is unique to the measurement and cannot be tied to another measurement. For observation arcs, a measurement is tied to both a scalar and a vector dataset. Again, this combination of datasets is unique to the measurement.

In addition to a unique *Name* and *Dataset(s)*, two other parameters are used to define the data represented by a measurement: *Trans* and *Module*. When analyzing data that varies through time, select the *Trans* toggle. The *Module* of a measurement refers to the SMS module where the computed data is stored. To create a new measurement:

1. Make sure “points” is selected as the *Feature object type*.
2. Type “Velocity” as the *Name* of the measurement.
3. Select “velocity” as the *Dataset* (not “velocity mag”).

Now that a measurement has been defined, observation points can be created and edited.

6 Creating an Observation Point

Observation points are created at locations in the model where the velocity or water surface elevation has been measured in the field. The measured values will be compared with the values computed by the model to determine the model’s accuracy. In addition to being assigned a *Color* and a *Name*, each observation point is assigned the following data:

- *Location*. The x, y real world location of the point needs to be specified. Observation arcs do not have these location attributes since several points define an arc.
- *Observed value*. The observed value is the value that was measured in the field corresponding to the active measurement.
- *Interval*. The interval is the allowable error (\pm) between the computed value and the observed value. Model verification is achieved when the error is within the interval (\pm) of the observed value.
- *Angle*. When a measurement for observation points is tied to a vector dataset (as is the case with the “Velocity” measurement created in the previous section) an angle needs to be specified. This angle is an azimuth angle with the top of the screen representing north when in plan view.

Name	X [ft]	Y [ft]	Angle	Observed Value [fps]	Interval [fps]
Point 1	190	-369	0.0.	3.5	0.25

Table 1: Observation point values

1. To create an observation point and set the appropriate information, enter the values shown in Table 1 for the *X* coordinate, *Y* coordinate, *Observed Value*, and *Interval*. Turn on the *Observe* toggle for this point. When the *Observe* toggle for a point or arc is on, it is said to be *Observed*.
2. Click **OK** to close the *Observation Coverage* dialog.

An observation point has now been created at the location specified in the *Observation Coverage* dialog. In this case, the model will be verified if the computed value is ± 0.25 fps of the observed velocity, or between 3.25 and 3.75 fps.


The *Observation Points* spreadsheet will always end with a blank line for the creation of additional points. (Note, there will be no blank line in the *Observation Arcs* spreadsheet since arcs cannot be created while in the *Observation Coverage* dialog.)

No angle has been specified for this point. This angle can be specified in the *Observation Coverage* dialog or in the Main Graphics Window.

If the point is not displayed, turn on the display of points:

1. Go to the *Display Options* dialog by selecting the *Display* menu then **Display Options....**
2. Under the *Map* section, turn on the points display by selecting the checkbox next to *Point*. A point with an arrow pointing up will appear in the *Graphics Window*. A calibration target is drawn next to the point. Click **OK** to close the *Display Options* dialog.

To specify the angle in the Main Graphics Window:

1. Using the **Zoom** tool, zoom in on the observation point.
2. Choose the **Select Feature Point**  tool from the *Toolbox*.
3. Select the observation point arrow and rotate the point arrow approximately 120° by dragging the end of the arrow clockwise. Do not worry if this angle is not exactly 120°. The arrow just needs to be pointing in the general direction the velocity meter was set up in the field. This is usually in the direction of flow. Figure 2 shows a close-up of “Point 1” with the arrow pointing up (0° angle) and then the position of the arrow at an angle of approximately 120°.




Figure 2 "Point 1" with an arrow angle of 0° and then rotated to 120°

6.1 Using the Calibration Target

A calibration target is drawn next to the observation point. The components of a calibration target are illustrated in Figure 3. These components are:

- *Target Middle*. This is the target value that was measured in the field.
- *Target Extents*. The top of the target represents the target value plus the interval while the bottom represents the target value minus the interval.
- *Color Bar*. The color bar shows the error between the observed value and the computed value. If the bar is entirely within the target, the color bar is drawn in green. If the error is less than twice the interval, the bar is drawn in yellow. A larger error will be drawn in red.

For this example, the bar would be green if the computed value is between 3.25 and 3.75, yellow for values between 3.0-3.25 or 3.75-4.0, and red for values smaller than 3.0 or greater than 4.0.





Figure 3 Calibration target

Now that the observation point has been created the target appears. The color bar in this example is red with an arrow pointing down, indicating that the computed solution has a velocity below 3.5 fps.

6.2 Multiple Measurements

Each observation point has attributes for all measurements. Similarly, each observation arc has attributes for each flux measurement. The highlighted measurement in the *Measurements* spreadsheet determines which attributes are shown in the *Observation Objects* spreadsheet.

For example, to create a new measurement:

1. Open the *Observation Coverage* dialog by choosing the **Select Feature Point**  tool from the *Toolbox* and double-clicking “Point 1.”
2. Type “WSE” as the *Name* in the bottom line of the *Measurements* spreadsheet. As with the *Observation Points* spreadsheet, the *Measurements* spreadsheet will always end with a blank line for the creation of additional measurements.
3. Press *Enter* or *Tab* to create the new measurement when finished typing to create the new measurement.
4. Select “water surface” as the *Dataset*.

Note that this new measurement is now the active measurement and it is also highlighted. Several measurements can exist at a time; however, calibration targets will only be displayed in the Main Graphics Window for *Observed* points in the active measurement.

Now look at the *Observation Points* spreadsheet. The *Name*, *Color*, and *X* and *Y* coordinates have remained the same for “Point 1,” however, the *Observed Value* and *Interval* have been reset to their default values. There is no *Angle* column as well since this new measurement is tied to a scalar dataset. These attributes are for the measurement named “WSE.” To view the observation point attributes previously specified for the *Velocity* measurement, simply click the *Velocity* measurement to highlight it in the *Measurements* spreadsheet.

Do not delete the “WSE” measurement since both it and the “Velocity” measurement will be used to calibrate the model.

1. Before continuing, make sure the “Velocity” measurement is the active measurement by checking the *Active* box in the “Velocity” row.

7 Reading a Set of Observation Points

Using the steps defined above, multiple observation points can be created. However, this process could become tedious for a large set of points. Normally, the data defining the points will be in spreadsheet format and can simply be copied and pasted in the *Observation Points* spreadsheet. To do this:

1. Outside of SMS, open the file “observepts.xls” in a spreadsheet program. (This is a Microsoft Office/Excel file. If using another spreadsheet program, the data is also contained in a tab delimited file named “observepts.txt.”)

2. Highlight the data from the column labeled *Name* to the first column labeled *int* for “Point 2” to “Point 8.” The data for “Point 1” does not need to be copied since “Point 1” has already been created.
3. Copy the selected data.
4. Return to SMS and make sure the “Velocity” measurement is selected.
5. Select the *Name* of the second row of the *Observation Points* spreadsheet as the starting cell for the data to be pasted and paste the copied data into the *Observation Points* spreadsheet.
6. Click **OK** to close the *Observation Coverage* dialog.

Seven new observation points appear in the *Graphics Window*. The new points are distributed around the finite element mesh, as shown in Figure 4.




Figure 4 Observation points created from the file *observepts.obt*

Now, the observed values and the confidence interval for the *WSE* measurement need to be specified. To do this:

1. Open the *Observation Coverage* dialog by double-clicking on one of the points.
2. Using the same spreadsheet file opened earlier, highlight and copy the data from the column labeled *wse* to the second column labeled *int* for “Point 1” to “Point 8.”
3. Return to SMS and make sure the “WSE” measurement is selected (highlighted).
4. Select the *Observed Value* of the top row of the *Observation Points* spreadsheet as the starting cell for the data to be pasted and paste the copied data into the *Observation Points* spreadsheet.


To view that calibration targets for the “WSE” measurement, make the “WSE” measurement the *Active* measurement and close the *Observation Coverage* dialog by clicking the **OK** button. The points that appear in the Main Graphics Window do not have arrows since the active measurement is observing a scalar dataset.

When calibrating a model the goal is to calibrate the model so that the computed values from the model fall within the confidence intervals of the observed field data for all measurements. At times this is difficult and personal discretion is required to determine when the model has sufficiently been calibrated.

1. Before continuing, make the “Velocity” measurement the active measurement by double-clicking any of the points to open the *Observation Coverage* dialog, and checking the *Active* box next to the “Velocity” measurement.

8 Generating Error Plots

SMS can create several types of plots to analyze the error between the computed and observed values. To create a *Computed vs. Observed Data* plot and an *Error Summary* plot

1. Select *Display / Plot Wizard...* . This will bring up the *Plot Wizard*.
2. Choose “Computed vs. Observed Data” as the *Plot Type*.
3. Click **Next** and choose “Velocity” as the *Measurement*.
4. Click **Finish** to close the *Plot Wizard* and generate the plot.

Create another plot of the “Velocity” measurement by repeating the steps above, but this time choose “Error Summary” as the *Plot Type*. Again choose “Velocity” as the *Measurement*.

Both plots have now been created. Each plot exists in a separate window that can be resized, moved, and closed at any time. The plots that appear are shown in Figure 5.




Figure 5 Computed vs. Observed Data and Error Summary plots

8.1 Plot Data

More plots can also be created for the “WSE” measurement or the current plots can be edited. To edit a plot:

1. Right-click the *Error Summary* plot and select **Plot Data...** from the menu.
2. Select “WSE” as the *Measurement*.
3. Click **OK** to close the *Data Options* dialog.

The *Error Summary* plot is now updated using the data from the “WSE” measurement.

8.2 Using the Computed vs. Observed Data Plot

In the *Computed vs. Observed Data* plot, a symbol is drawn for each of the observation points. A point that plots on or near the diagonal line indicates a low error. Points far from the diagonal have a larger error. The position of the points relative to the line gives an indication whether the computed values are consistently higher or lower than the observed values. In this case, all points are below the line indicating that all computed velocities are lower than observed values.

1. Change the measurement for the *Computed vs. Observed Data* plot to the “WSE” measurement by following the steps above defined in section 8.1.

Now, all points plot above the line indicating that all computed water surface elevations are above the observed values.

8.3 Using the Error Summary Plot

In the *Error Summary* plot, the following three types of error norms are reported:

- *Mean Error*. This is the average error for the points. This value can be misleading since positive and negative errors can cancel.
 - *Mean Absolute Error*. This is the mean of the absolute values of the errors. It is a true mean, not allowing positive and negative errors to cancel.
 - *Root Mean Square*. This takes the sum of the square of the errors and then takes its square root. This norm tends to give more weight to cases where a few extreme error values exist.
1. Close the two plots now by clicking on the “X” at the upper right corner of the window.
 2. Then, maximize the graphics window and frame the image, using the **Frame** macro.

9 Calibrating the Model

The values in this solution for both measurements are not within the calibration targets. To achieve better calibration, the material properties will be changed and then the model will be re-run using FESWMS. If the FESWMS interface isn't enabled, solutions using a generic mesh have been provided. Since the errors through the main channel for the “Velocity” measurement are negative, indicating that the observed velocities are larger than those computed by the model, it's necessary to change the parameters in such a way as to increase the velocity in these locations (eddy viscosity and/or Manning's n). Increasing the velocity at these locations should also decrease the water surface elevation.

9.1 Editing the Material Properties

Decreasing the eddy viscosity values can increase these computed velocities. To decrease the eddy viscosity:

1. Click on the **Mesh** module to make it active.
2. Select *FESWMS / Material Properties....* This will bring up the *FESWMS Material Properties* dialog.
3. In the *Turbulence Parameters* tab, change the Vo (kinematic eddy viscosity) value from “10.0” to “1.5.”
4. Click **OK** to close the *FESWMS Material Properties* dialog.

9.2 Computing a New Solution

To compute the new solution:

1. Go to *File / Save As...*, make sure the type is SMS project file and save the simulation as “observe2.sms.”
2. Use the command **Run FST2DH** in the *FESWMS* menu on the new simulation. This will open the *Model Checker* dialog.
3. Select **Run Model**. At the completion of the run, leave the toggle on for reading the solution. It may be necessary to select a different dataset in the Project Explorer for the targets to update after running FST2DH.

9.3 Reading the New Solution

If unable to run FESWMS successfully, the solution for the second simulation can be opened by selecting the *File / Open...* command and selecting the file “observe2.flo”.

- Generic Module Instructions: Select *File / Open...* and choose “observe2.h5.” The user should see solutions for both the *observe1* model and the *observe2* model.

The calibration targets will automatically update to show the errors for the solution that was just opened.

9.4 Fine-tuning the Model

The verification targets now show that six points for the “Velocity” measurement are within the allowable range and two points are above the range, but still in the yellow range. There are no points more than the two times the variation above the observed value (red targets). Looking at targets for the “WSE” measurement, four points are within the allowable range and four are below the range with one point being more than two times the variation below the observed value. Since the values for the “Velocity” measurement that are unacceptable are now higher than the observed values and the values for the “WSE” measurement that are unacceptable are now lower than the observed values, the correction made was too drastic. Specifically, the eddy viscosity was lowered too much and it needs to be raised. To compute another solution:

1. Click on the Mesh module to make it active.
2. Select *FESWMS / Material Properties....* This will bring up the *FESWMS Material Properties* dialog.
3. In the *Turbulence Parameters* tab, change the *Vo* (kinematic eddy viscosity value) from “1.5” to “6.0.”
4. Click **OK** to close the *FESWMS Material Properties* dialog.
5. Go to *File / Save As...*, make sure the type is SMS project file and save the simulation as “observe3.sms.”
6. Run a third simulation of FST2DH (“observe3.sms”). (Read in the simulation at the completion of the run or read the solution from the output folder labeled “observe3.h5.” This is the generic solution.)

After this third simulation is opened, all the observation point targets for the “Velocity” measurement should be within the acceptable intervals. Make sure velocity is the active measurement and confirm this.


Now make the “WSE” measurement the *Active* measurement (in the *Observation Coverage* dialog accessed through the *Feature Objects* menu in the *Map* module). All but two points are within the acceptable interval. To get these two points within range, compute another solution:

1. In the *FESWMS Material Properties* dialog (accessed through the *FESWMS* menu in the *Mesh* module), change the kinematic eddy viscosity value (V_0) to “7.0”
2. Go to *File / Save As...*, make sure the type is SMS project file and save the simulation as “observe4.sms.”
3. Run a fourth simulation (“observe4.sms”). (Read in the simulation at the completion of the run or read the solution from the output folder labeled “observe4.h5.” This is the generic solution.)

Looking at the calibration targets should show all the points are acceptable. The calibration process is now complete. It will not always be possible to get all observation points for each measurement to be within the acceptable confidence interval. Therefore, it will have to be decided which measurements and which points are the most important to have within the acceptable range.

10 Using the Error vs. Simulation Plot

When performing trial-and-error verification, it is often important to keep track of the error trend as new solutions are repeatedly computed. SMS provides a special verification plot to simplify this task. To create this plot:

1. Select *Display / Plot Wizard...* . This will bring up the *Plot Wizard*.
2. Choose “Error vs. Simulation” as the *Plot Type* and click **Next**.
3. Select “Velocity” as the *Measurement*.
4. SMS will create a plot with one point for each simulation. The order of the points in the plot will follow the order solution sets in the *Solutions* list box. The solution at the top will be first. Use the **Move Up** and **Move Down** buttons to change this order. The default order is the order that they were read in.
5. Click **Finish** to close the *Plot Wizard* and generate the plot.

A new plot appears showing the *Error vs. Simulation*, as shown in Figure 6. Notice for the “Velocity” measurement that the errors decrease as each simulation was performed until the final solution where the errors slightly increase. This slight increase in error with the “Velocity” measurement was required to get that last observation point for the “WSE” measurement within the acceptable range. Generally, if the errors increase, then the model is not improving.




Figure 6 Error vs. Simulation plot for Velocity

Create another *Error vs. Simulation* plot using the “WSE” measurement. The errors for this measurement changed dramatically from solution to solution since parameters were first changed to calibrate points for the “Velocity” measurement. However, the general trend was a decrease in error. This plot is shown in Figure 7.





Figure 7 Error vs. Simulation plot for WSE

Close the plots now by clicking on the “X” at the upper right corner of the window.


11 Generating Observation Profile Plots

Observation profile plots are used to view dataset values along observation arcs. The first observation arc to be created will be used to create a profile of the main channel. To create this arc:


1. Right-click on the “Map Data” folder in the Project Explorer and create a **New Coverage**.

2. In the *New Coverage* dialog, make the *Type* an *Observation* coverage and make its name “Profiles.”. Click **OK**.
3. Click on this new coverage to make the Map module active. (It's useful to create a separate coverage to keep the observation arcs separate from the existing observation points. When an observation arc is being created, observation points may be clicked joining them to the arc. Observation points and arcs can exist on the same coverage.)
4. Choose the **Create Feature Arc**  tool from the *Toolbox*.
5. Create an arc down the main channel, as shown in Figure 8. Remember to double-click the last point to end the arc.

When the plots are drawn, they will use the name and color associated with the observation arc. To change the name and color of the arc:

1. Choose the **Select Feature Arcs**  tool from the *Toolbox*.
2. Double-click on the profile arc.
3. In the *Observation Coverage* dialog, change the *Name* of the arc to “river profile” in the *Observation Arcs* section (leave it's *Color* as the default).
4. Click **OK** to close the *Observation Coverage* dialog.

Three more arcs need to be created, each across a section of the river. These arcs will be used to create cross section plots. To create these arcs:

1. Select the **Create Feature Arcs**  tool from the *Toolbox*.
2. Create each of the cross section arcs, as shown in Figure 8. Note: When creating these, DO NOT click ON the profile arc, as this would split it.





Figure 8 Profile and cross section arcs

With the cross sections created, open the *Observation Coverage* dialog by double-clicking on one of the arcs and assign a unique color and an appropriate name to each arc. When finished, click **OK** to close the *Observation Coverage* dialog.

With the arcs created, the plots can now be generated. To do this:

1. Select *Display / Plot Wizard...*  to bring up the *Plot Wizard*.
2. Choose “Observation Profile” as the *Plot Type* and click **Next**.
3. Turn on the *Dataset Specified* option, and check only the “elevation” dataset in the *Generic Solution* and the “water surface” dataset in the *observe4.flo* solution.
4. Turn off the three cross section arcs in the *Arcs* spreadsheet by turning off their corresponding *Show* toggles.
5. Click **Finish** to close the *Plot Wizard* and generate the plot.

The profile plot of the geometry of the stream should appear as shown in Figure 9.

To view the velocity distribution across the three cross sections:

1. Create a new *Observation Profile* plot, by following the steps above. Turn on the “velocity mag” dataset in the *observe4.flo* solution, and *Show* only the three cross section arcs.
2. When done, close the profile plot.




Figure 9 Observation Profile Plot

12 Generating Time Series Plots

As mentioned earlier, observation arcs are used to compute fluxes. One flux value that is often observed and measured in the field is flow rate. Observed flow rates can be used in model calibration in the same way observed velocities and water surface elevations are used. In addition to normal model calibration, *Time Series* plots can be generated

showing how the flow rate flux changes with time. This type of time series plot is commonly known as a hydrograph. Hydrographs created using calculated data from the model are useful to see if the model properly predicts flow rate patterns. To create a *Time Series* plot:






Figure 10 Observation arc across noyo1.sms mesh

1. Select *File* / **Open...** This will cause the *Open* dialog to appear.
2. Open the file *noyo1.sms* if the *FESWMS* interface is enabled. If not, open the files *noyo1.2dm* and *noyo1.h5*.
 - If geometry data is still open, a warning will appear that the existing mesh will be deleted. If this happens, click **Yes** to the prompt.
3. Right-click on the “Map Data” and select **New Coverage** from the menu. This will open the *New Coverage* dialog.
4. Select “observation” for the *Coverage Type* and in the text box, name the coverage “Fluxes.”
5. Click on the **Frame**  button.
6. Go to *Display* / **Display Options** to bring up the *Display Options* dialog.
7. In the *2D Mesh* tab turn on *Elements* and *Nodes*. Then click **OK**.
8. Create an observation arc across the mesh as shown in Figure 10, using the **Create Feature Arc** tool.
9. Open the *Plot Wizard* , by selecting *Display* / **Plot Wizard**.
10. Choose “Time Series” as the *Plot Type* and click **Next**.
11. Change the *Function Type* to “Flux.” Check the *Show* toggle in the spreadsheet for the arc that was just created (the default name will be “Arc 1”). Select “water depth” as the *Scalar Dataset* and “velocity” as the *Vector Dataset*.
12. Click **Finish** to close the *Plot Wizard* and generate the plot.

A new window opens with the *Time Series* plot of the *Flow Rate* flux measurement. This plot should appear similar to the one in Figure 11.




Figure 11 Time Series plot of Flow Rate.

13 Conclusion

This concludes the *Observation Coverage* tutorial. The user may continue to experiment with the program or may exit SMS.